



HEATMOR™


STAINLESS STEEL
Outdoor Furnaces

Manufactured By:

HEATMOR™

105 Industrial Park Ct. NE,
P.O. Box 787
Warroad, MN 56763

MY DEALER IS:



RESPONSE™

A second generation furnace.

HEATMOR
Quality Since 1984




Model
200SSRII

OPERATIONS AND MAINTENANCE MANUAL

OUTDOOR WOOD FURNACE BEST BURN PRACTICES

1. Read and follow all operating instructions supplied by the manufacturer.
2. **FUEL USED:** Only those listed fuels recommended by the manufacturer of your unit. Never use the following: trash, plastics, gasoline, rubber, naphtha, household garbage, material treated with petroleum products (particle board, railroad ties and pressure treated wood), leaves, paper products, and cardboard.
3. **LOADING FUEL:** For a more efficient burn, pay careful attention to loading times and amounts. Follow the manufacturer's written instructions for recommended loading times and amounts.
4. **STARTERS:** Do not use lighter fluids, gasoline, or chemicals.
5. **LOCATION:** It is recommended that the unit be located with due consideration to the prevailing wind direction.
 - Furnace should be located no less than 100 feet from any residence not served by the furnace.
 - If located within 100 feet to 300 feet to any residence not served by the furnace, it is recommended that the stack be at least 2 feet higher than the peak of that residence.



6. Always remember to comply with all applicable state and local codes.

Wiring Diagram
Model 200 SSR II

